

XTENDER-E Electronic 1.4" to 6" Dial Bore Gage Set



Xtender Indicator Shroud
Part Number: 05-100-265



Xtender Shroud Bar
Part Number: 05-100-287



Indicator Only for 54-646-401
Part Number: 54-666-025



Description	Part Number	Length (L)
Xtender Anvil 2" Long	05-100-234-0	0.742"
Xtender Anvil 2.2"	05-100-235-0	0.951"
Xtender Anvil 2.4"	05-100-236-0	1.150"
Xtender Anvil 2.6"	05-100-237-0	1.353"
Xtender Anvil 2.8"	05-100-238-0	1.548"
Xtender Anvil 3.0"	05-100-239-0	1.749"
Xtender Anvil 3.2"	05-100-240-0	1.950"
Xtender Anvil 3.4"	05-100-250-0	2.152"
Xtender Anvil 3.6"	05-100-251-0	2.348"
Xtender Anvil 3.8"	05-100-252-0	2.549"
Xtender Anvil 4.0"	05-100-253-0	2.751"

Note: Anvils listed are for the 2-6" measuring head. Length (L) for each anvil is an approximate measurement taken with a caliper for assistance in anvil identification.



Description	Part Number	Length (L)
Xtender Anvil 1.4"	05-100-254-0	0.575"
Xtender Anvil 1.6"	05-100-255-0	0.780"
Xtender Anvil 1.8"	05-100-256-0	0.979"
Xtender Anvil 2" Short	05-100-257-0	1.185"

Note: Anvils listed are for the 1.4-2" measuring head. Length (L) for each anvil is an approximate measurement taken with a caliper for assistance in anvil identification.



Xtender 2-6" Measuring Head
Part Number: 05-100-261



Xtender Clamp w/ Screw
Part Number: 05-100-263



Xtender 1.4-2" Measuring Head
Part Number: 05-100-262



Xtender Clamp Screw
Part Number: 05-100-428



Xtender Anvil Locking Nut
Part Number: 05-100-264



Xtender Washer Set
Part Number: 05-100-259



Xtender 2" Extension
Part Number: 05-100-258

Part Number	Description
54-646-401-0	XTender-E Bore Gage Set
54-100-350-0	CR2032 Battery

Bore Gages

Specifications subject to change without notice.